


## FT-802 Installation manual



# 18-22卡罗拉/凯美瑞/RAV4 燃油车安装位置 FT-802



享科二维码  
用户 oIEAcy

---

## learning method

>>



Between each step, the LED will turn to pure red, which is the default

01



Press the start button twice to the on position.

02



After a few seconds, the LED will turn green and go out

03



Press the start button once to the off position.

04



Learning is complete.

Remote start : press lock button of the original key 3 times

Remote stop : press lock button of the original key 3 times after remote started